

The Do's and Don'ts of Application:

Applying *Construct Wrap* peelable coatings are very simple, however I am going to give a few tips on the Do's and Don'ts in order to make the process even easier. Before I start with the product, here are a couple of pointers on the surface.

1. Ensure that the substrate you are about to apply the *Construct Wrap* to is a suitable substrate - for example, if the surface is porous or unsealed, chances are you are going to have difficulty in peeling off the protection coat. This is because *Construct Wrap* is specifically designed to be applied to **non-porous** substrates or surfaces that are adequately sealed as not to permeate fluid or air.



Moreover if the surface is heavily textured this will also effect the peel-ability of the coating. This is because the peaks and troughs in a textured surface act like a Velcro surface and grip to the coating sufficient to cause difficulties in peeling. Always do a 'spot test' by applying a small area first and check its peel-ability.

2. The most suitable substrates are:

- ✓ Glass
- ✓ Granite
- ✓ Vitrified tiles
- ✓ Laminates
- ✓ Porcelain
- ✓ Fiberglass
- ✓ 2-pac coatings



3. Don't forget to ensure the surface is clean and free from any dust, dirt, grease, and oil.



Also ensure no rain is present or forecast, especially if you are applying *Construct Wrap* externally. The last thing should be ambient temperature - *Construct Wrap* needs to be applied between 10 and 40 degrees Celsius. Oh, and don't forget to stay in the shade – the direct sun will skin the material very quickly and if you are still rolling, this can get messy.

Right, we're ready to start, stir the material lightly and don't add anything else to the product as it could affect the product performance. You can use a brush, or spray gun, but we recommend using a 12mm nap roller approximately 180mm wide. Apply the material evenly and consistently – approximately 200 micron wet - around twice the thickness of exterior paint, this will dry thinner and create an excellent film from which to peel off when ready. Don't worry if you can't finish an area, you can come back and continue later without affecting the peel-ability – just make sure where the join is, it's nice and thick. If you have an edge where you want to stop at, either use masking tape or keep your edge thick so it's easy to peel when ready. If you are applying the Floor coat and have areas of high traffic and high impact risks, two coats is required as a minimum. Although *Construct Wrap* will dry within one hour you will need to leave at least 2 hours before



applying additional coats. Depending on the product you are using, application rates should be around 3-6 sqm per kg. Please refer to the specific instructions relevant to each product for more detailed information.

